

Right ahead
direction


Signal-
Nullrichtung

Direction
signal zero

Cable entry

Kabel-
einführung

Entrée de
câble



- Pin connections:
3 tricolor light /
masthead light
2 anchor light

- Pin Belegung:
3 Dreifarben Licht /
Topp Licht
2 Anker Licht

- Lignes de Raccor-
dement:
3 Feu tricolore /
Feu de mât
2 Feu de mouillage