



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)

S/N J48494



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)



### BL-SL-L

Thankyou for purchasing BEP products.

**Note:** If you have purchased your GDL, GD, FD2 before S/N J48494 found on the meter rear cover, Please fit the enclosed 82k resistor between the terminals of G and R on the back of the meter case. If you have purchased your GDL, GD, FD2 **AFTER** S/N J48494 , Please discard the resistor.

[www.bepmarine.com](http://www.bepmarine.com)